



How to enter into “Emergency State”

Steps:

1. Power off the dsp controller, and then push OK button.
2. Do not let it pop up from your finger, keep pushing it.
3. Power on the dsp and waiting the loading for 5 seconds.
4. About loading to 80%, release the OK button.
5. It will enter into “emergency state”.
6. Choose “Format system”, after that, choose “Update system”.
7. Plug the U disk with latest firmware into the controller.
8. Select “U disk file” option, and find the latest update pack.
9. Reboot the dsp system after the updating is completed.



From RichAuto

e:t41@richnc.com.cn

Contact Rowena to help U~